VISUAL COMFORT & CO.

GENERATION LIGHTING

KERRVILLE 1, 2, 3 & 4 LIGHT WALL

4115201, 4415202, 4415203, 4415204

General Product Information

ETL LISTED Intertek	SAVE THESE INSTRUCTIONS!	STANDARD INSTALLATION	TITLE 24 COMPLIANT
DIMMER COMPATIBLE	BULB(S) (NOT INCLUDED)	NEC COMPLIANT JUNCTION BOX	DAMP LOCATION SAFE
LED	PLEASE SEE visualcomfort.com FOR PRODUCT SPECS	CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!	BEST PRACTICE: HANDLE FIXTURE WITH GLOVES

WARRANTY

FCC STATEMENT

Tools Required

PHILLIPS-HEAD SCREWDRIVER

Safety Information

CAUTION-RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.

Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.

JUNCTION BOX · MOUNTING PLATE · LAMP · SHADE TOOL · COLLAR NUT · SHADE · SOCKET · CAP NUT · FIXTURE BASE · MOUNTING PLATE STUD

INSTRUCTIONS

I.   Preparing the Fixture

1.   Secure the mounting plate to the junction box.

III. Wiring the Fixture

1.   Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2.   In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around, or a house wire (green or bare copper wire without insulation).
3.   Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
       a)   White fixture wire to neutral power line wire
       b)   Black fixture wire to hot power line wire
4.   Mount the fixture base onto the mounting plate stud(s) and secure it using the cap nut(s).
5.   Place the shade onto the socket and secure it in place by screwing the collar nut onto the socket using the shade tool. Repeat with remaining shades.
6.   Screw the lamps into the sockets. Refer to the socket for Max Wattage information.