



FOR YOUR SAFETY **HC-215**
INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY **HC-215**
INSTALLATION AND SAFETY INSTRUCTIONS

INSTALLATION AND SAFETY INSTRUCTIONS
FOR YOUR SAFETY **HC-215**

INSTALLATION AND SAFETY INSTRUCTIONS
FOR YOUR SAFETY **HC-215**

WARNING: Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off

WARNING: RISK OF SHOCK, 24V SYSTEM NOT SUITABLE FOR OUTDOOR USE.

CAUTION: RISK OF FIRE. USE ONLY 12V LAMPS WITH 12V SYSTEMS. USE OF 12V LAMPS WITH 24V SYSTEM MAY RESULT IN DAMAGE TO SYSTEM AND SURROUNDING AREA

WARNING: Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off

WARNING: RISK OF SHOCK, 24V SYSTEM NOT SUITABLE FOR OUTDOOR USE.

CAUTION: RISK OF FIRE. USE ONLY 12V LAMPS WITH 12V SYSTEMS. USE OF 12V LAMPS WITH 24V SYSTEM MAY RESULT IN DAMAGE TO SYSTEM AND SURROUNDING AREA

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

ACCENT LIGHT INSTALLATION
(USE ONLY WITH AMBIANCE 105° CABLE)

ACCENT LIGHT INSTALLATION
(USE ONLY WITH AMBIANCE 105° CABLE)

- A. Space Accent lights no closer than 6" apart.
 - B. Snap lamp (18w max.) into socket.
 - C. Making sure contacts on head are aligned with cable, press head onto the track until both sides of head snap onto the track.
- NOTE: Loosen screws to rotate shade if necessary.

- A. Space Accent lights no closer than 6" apart.
 - B. Snap lamp (18w max.) into socket.
 - C. Making sure contacts on head are aligned with cable, press head onto the track until both sides of head snap onto the track.
- NOTE: Loosen screws to rotate shade if necessary.

WARNING: Use of other manufacturers components will void warranty, U.L. listing and create a potential safety hazard.

WARNING: Use of other manufacturers components will void warranty, U.L. listing and create a potential safety hazard.

RISK OF FIRE: DO NOT REMOVE REFLECTOR.

RISK OF FIRE: DO NOT REMOVE REFLECTOR.

CAUTION RISK OF FIRE. 12V LAMPS MUST NOT BE USED IN A 24V SYSTEM. INSTALL CABLE SO THAT CAUTION PRINTED ON CABLE IS VISIBLE AFTER INSTALLATION AND ATTACH THE 24V CAUTION LABELS (SUPPLIED WITH THE 24V TRANSFORMER) ON OR ALONG THE TRACK EVERY 4 FT.

CAUTION RISK OF FIRE. 12V LAMPS MUST NOT BE USED IN A 24V SYSTEM. INSTALL CABLE SO THAT CAUTION PRINTED ON CABLE IS VISIBLE AFTER INSTALLATION AND ATTACH THE 24V CAUTION LABELS (SUPPLIED WITH THE 24V TRANSFORMER) ON OR ALONG THE TRACK EVERY 4 FT.