










METROPOLIS ONE LIGHT WALL/BATH SCONCE

41036

General Product Information

 <p>Intertek</p>	 <p>SAVE THESE INSTRUCTIONS!</p>	 <p>STANDARD INSTALLATION</p>	 <p>INDOOR</p>
 <p>DAMP LOCATION SAFE</p>	 <p>NEC COMPLIANT JUNCTION BOX</p>	 <p>CONVERTS TO LED</p>	 <p>BULB(S) (NOT INCLUDED)</p>
 <p>INSTALL IN ADHERANCE WITH LOCAL ELECTRICAL CODES</p>	 <p>CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!</p>	 <p>BEST PRACTICE: HANDLE FIXTURE WITH GLOVES</p>	 <p>PLEASE SEE visualcomfort.com FOR PRODUCT SPECS</p>





Product Warranty



FCC Statement

Suggested/Required Tools


 <p>ELECTRIC DRILL</p>	 <p>PHILLIPS-HEAD SCREWDRIVER</p>	 <p>WIRE CUTTER</p>
---	--	--

Safety Information

CAUTION-RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.




Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.



FIXTURE PARTS



- A. Junction box
- B. Wire nut connections
- C. Mounting plate
- D. Threaded nipple & hex nut
- E. Mounting screws
- F. Bulb
- G. Backplate
- H. Cap nut
- I. Socket
- J. Support
- K. Shade
- L. Thumb screws

INSTRUCTIONS

I. Preparing the Fixture

1. If necessary, install the threaded nipple to the mounting plate with the hex nut.
2. Secure the mounting plate to the junction box.

II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
3. Adjust the length of any of the wires using a wire cutter/stripper if necessary.
4. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot (black) fixture wire to hot power line wire
 - b) Neutral (white) fixture wire to neutral power line wire
5. Carefully tuck all the wires into the junction box.

III. Installing the Fixture

1. Screw the bulb into the socket. Refer to the socket label for max wattage information.
2. Place the shade onto the supports and secure it in place with the two thumb screws.