





SUNSET DRIVE SMALL 2L FLUSH MOUNT

FM313

General Product Information



Suggested/Required Tools



Safety Information

CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.
Install and use this product in adherence with local electrical codes and regulations.





INSTRUCTIONS

I. Preparing the Fixture

1. Attach mounting bar securely to ceiling junction box with two machine screws through the slot at each end of the mounting bar. **Note: Mounting bar should be installed with “GND” imprint and/or two dimples facing down.**
2. Fasten one hex nut about $\frac{3}{4}$ " (19 mm) down from one end of the threaded pipe. Screw the same end of the threaded pipe into the center hole of the mounting bar. Ensure $\frac{3}{8}$ " (10 mm) of pipe protrudes. Remove the main frame and tighten the hex nut against the mounting bar. Make sure not to spin threaded pipe during tightening.
3. Spread electrical wires so that the black wires are on one side of the outlet box and the white wires are on the other.

II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire to hot power line wire
 - b) Neutral fixture wire to neutral power line wire
4. Carefully tuck all the wires into the junction box.

III. Installing the Fixture

1. Tuck all electrical wires into the frame and install the main frame by fastening with a lock washer and coupler onto the top threaded pipe.
2. Install a hex nut onto one end of the center pipe, leaving about $\frac{3}{8}$ " (10 mm) of thread exposed. Screw the same end of the pipe into the coupler and tighten the hex nut.
3. Install the bulb. See the label on the socket for maximum wattage information.
4. Install the shade by slipping it through the installed center pipe and fastening it with the finial. **Do not over-tighten.**